

DEGREASER

Ingredients available at
<https://ecomarkcare.co.za/shop/shop-at-ecomarkcare/>

Raw Materials Needed: 100 liters

25 kg Non-Ionic (9 mole)

1.25 kg Xylol

95 kg Power paraffin

METHOD

Into a plastic container pour
1.25 ml of Non-Ionic.

Premix 625 ml of Xylol with
625 ml of Non-Ionic. Stir
together in a small plastic
container. Add this mixture
to the Non-ionic in the main
container.

Add 47.5 liters of Power
paraffin and stir well with a
mixing stick.

This product is Flammable.
Do not work in vicinity of a
heat source. Work in well
ventilated area. Do not inhale
fumes.

SHOP RAW MATERIALS

[https://ecomarkcare.co.za/s
hop/shop-at-ecomarkcare/](https://ecomarkcare.co.za/shop/shop-at-ecomarkcare/)

NEED MORE INFO

WHATSAPP US:

[HTTPS://WA.ME/MESSAGE/OK
K5LUGHJQTD1](https://wa.me/message/OKK5LUGHJQTD1)

CALL US: 068 219 3103

EMAIL:

info@ecomarkcare.co.za

HOW TO USE:

Spray onto greasy parts with a hand sprayer (trigger-gun type) or dip and soak

greasy parts in a deep open-top tray. Brush lightly and then rinse with a jet of

water.

APPLICATION:

Workshops, garages, factories, motor industry, shipping, fishing industry.

