

Ingredients available at https://ecomarkcare.co.za/shop/shop-at-ecomarkcare/

Raw Materials Needed:

Makes 10 liters

- liter water
- liter SLES (25% strength)
- liter CDE
- Butyl Oxitol

METHOD

Mix thoroughly together, all the ingredients in the order that it is listed, one by one. Dilute 1 to 25 or more when using.

SHOP RAW MATERIALS

https://ecomarkcare.co.za/ s

hop/sho p-at-ecomarkcare /

NEED MORE INFO

WHATSAPP US:

HTTPS://WA.ME/MESSAGE/O K

K5LUGHJQTDM 1

CALL US: 068 219 3103

EMAIL:

info@ecomarkcare.co.za